

SELECT Monitor

Technical data

THE SELECT-MONITOR is designed to address the problem of – How much feed is left in the silo (feed silo)?

Knowing how much feed remains in a silo is critical. An unexpectedly empty silo has serious welfare implications, as well as placing strain on the supply company which has to deliver feed at short notice.

Features include:

- Easy calibration – All feeds have a different compositions and hence a different performance in augers. The Select Monitor has a 1 minute calibration procedure that is accurate as well as fast.
- Daily usage rate is shown for each silo as well as the quantity remaining in the silo.
- Up to 6 silos can be connected by cable to one Select-Monitor. Each can be calibrated separately.
- Where multiple augers feed from the same silo, these augers can be linked to give an accurate picture of what remains in the common silo.
- Where one or more augers service multiple silos, those silos can be marked as Active or Not Active as an Option, depending on whether feed is being taken from a silo or not.
- Installation is quick and simple. Full instructions given in the Instructions for Use.

Coming soon:

The Select-Monitor will be able to be connected to the General-Alert system. More details soon....

